



VIOLIN AND VIOLA CASES FOR CONCERT ARTISTS SINCE 1983  
a division of Musafia Italia S.r.l. (Ltd)

## DIGITAL THERMO-HYGROMETER

### *Instructions for Use*

Updated March 28, 2011

The electronic thermometer-hygrometer in your Musafia case is a useful device which will help you care for your violin or viola. It is mounted inside the case in such a way to allow it to be easily detached for use outside of the case and in order to change the battery. Please keep these instructions handy for reference.

#### 1) General use

- For acoustic string instruments, optimal relative humidity is between 40% and 70%. If humidity drops below these levels please use a humidifier to help ensure your instrument won't crack or unglue.
- The digital display can display the air temperature in Fahrenheit or Centigrade by briefly depressing the button on the left.
- The highest and lowest temperature and humidity are memorized and can be recalled by briefly depressing the button on the right.
- Holding the button on the right depressed for two seconds resets the memory feature.

#### 2) How to detach the thermo-hygrometer from the case (if supplied installed in the case)

- Slip the elastic safety ribbon off.
- Slide the device upwards to unhook it from the screw that holds it in place

#### 3) Characteristics

- Temperature and humidity readings updated every 10 sec.
- Thermometer readout in °C and °F, increments of 0.1 degrees
- Memory feature with min.- max. recording of both temperature and relative humidity
- Thermometer accuracy +/- 0.5°C circa; hygrometer accuracy +/- 3% circa
- Thermometer range: -10 C° to 50 °C (14°F to 122°F)
- Uses 1 AAA battery

Administration and Atelier: Via Novati, 4 26100 Cremona, Italy  
tel. (+39) 0372-455047 (+39) 0372-454314 Fax (+39) 0372-454089 e-mail: info@musafia.com

www.musafia.com